

# EMPIRE®

UPDATED 1/1/10  
**NOW SHIPPING**  
**UPDATED**  
**MODELS**

## UNIVERSAL TWO-SIDED REPLACEMENT DIGITAL / VIDEO CHARGERS



### Features:

- Reverse Polarity Protection
- Fully Functional - No Plates to Attach
- Quick Charge with 2 Color LED
- 100-240V for Worldwide Travel
- UL with Auto Cut Off for Safety
- Lightweight AC/DC
- Easy to Use with Mounting Instructions
- Countertop/Hanging Clam Packaging
- Covers to Protect Contacts

**LIFETIME WARRANTY**

### MAXIMUM CHARGING TIME FOR ALL CHARGERS

VOLT	CAPACITY	TIME
3.6/3.7V	500 mAh	1 Hour
3.6/3.7V	1000 mAh	2 Hours
7.2/7.4V	1000 mAh	2 Hours
7.2/7.4V	2000 mAh	4 Hours



SONY
  CANON
  PANASONIC
  KODAK & FUJI & CASIO
  OLYMPUS & FUJI
  SAMSUNG
  NIKON
  JVC
  KONICA / MINOLTA
  PENTAX & RICOH & SANYO

### EMPIRE CENTRAL

381 Randy Road  
 Carol Stream, IL 60188  
 Phone: (800) 221-6012  
 Fax: (800) 719-9902

### HEADQUARTERS

P.O. Box 817  
 151 East Industry Court  
 Deer Park, NY 11729-5713  
 Phone: (800) 645-7220  
 Fax: (800) 343-5733

### EMPIRE SOUTH

4504 E. Hillsborough Ave.  
 Tampa, FL 33610  
 Phone: (800) 810-8891  
 Fax: (877) 422-8866

VISIT US ON THE WEB: [www.empirescientific.com](http://www.empirescientific.com) ● E-MAIL: [sales@empirescientific.com](mailto:sales@empirescientific.com)

# SONY

# CANON

# PANASONIC

# KODAK & FUJI & CASIO

# OLYMPUS & FUJI

## DVU-SON1 R1

## DVU-CAN1 R1

## DVU-PAN1 R1

## DVU-KFC1 R1

## DVU-OLF1 R1



	SONY	EMPIRE
SIDE A	A NP-FA50,70	BLI-263
	D NP-BD1,FD1	BLI-334
	E NP-FE1	BLI-274
	G NP-BG1	BLI-287
	H NP-FH50,70,100	BLI-308
	K NP-BK1	BLI-351
	P NP-FP30,50,70,90	BLI-246
	R NP-FR1	BLI-253
	T NP-FT1	BLI-247
	SIDE B	C NP-FC10,11
F NP-FF50,51,70,71		BLI-209
L NP-F330,550,570,730,750,950		BLI-153
M NP-FM50,70,90,QM71,91		BLI-180
S NP-FS10,11,12,21,22,31,32		BLI-173

	CANON	EMPIRE
SIDE A	BP-208	BLI-279
	BP-308,310,315	BLI-280
	BP-809,819,827	BLI-338
	BP-808	BLI-376
	LP-E5	BLI-350
	NB-4L	BLI-256
	NB-5L	BLI-297
	NB-6L	BLI-348
	NB-7L	BLI-356
	SIDE B	BP-511,512,522,535
BP-608,617		BLI-169
BP-911,930,945		BLI-161
NB-1L,1LH		BLI-198
NB-2L,2L12,2L14		BLI-204
NB-3L		BLI-233

	PANASONIC	EMPIRE
SIDE A	CGA-D54S	BLI-262
	CGA-DU-07,14,21	BLI-230
	CGA-S001,1E,DMW-BCA7	BLI-226
	CGR-D120,220,320	BLI-172
	CGR-S602A,603	BLI-218
	DMW-BCF10,BCF10E <b>NEW</b>	BLI-367
	DMW-BCG10,10E,10PP <b>NEW</b>	BLI-368
	DMW-BLB13,13E,13PP <b>NEW</b>	BLI-361
	VBG-130,260	BLI-307
	SIDE B	CGA-S002
CGA-S003		BLI-237
CGA-S005		BLI-284
CGA-S007,007E		BLI-298
CGA-S008E		BLI-319
CGA-S302		BLI-241
CGR-S006A,006E,DMW-BMA7		BLI-283
CGR-S101A,B,DMW-BC7		BLI-219
VW-VBA10,12		BLI-203

	KODAK & CASIO & FUJI	EMPIRE
SIDE A	KODAK KLIC-7001	BLI-286
	KODAK KLIC-7002	BLI-285
	KODAK KLIC-7003	BLI-310
	KODAK KLIC-7004	BLI-330
	KODAK KLIC-7005	BLI-321
	CASIO NP-20	BLI-216
	CASIO NP-40	BLI-251
	CASIO NP-60	BLI-337
	CASIO NP-70	BLI-353
	FUJI NP-30	BLI-255
SIDE B	FUJI NP-50	BLI-329
	KODAK KLIC-3000	BLI-183
	KODAK KLIC-5000	BLI-203
	KODAK KLIC-5001	BLI-236
	KODAK KLIC-7000	BLI-261
	KODAK KLIC-7006	BLI-327
	KODAK KLIC-8000	BLI-300
	CASIO NP-30	BLI-203
	CASIO NP-50	BLI-316
	CASIO NP-80	BLI-365
SIDE B	CASIO NP-82 <b>NEW</b>	BLI-272
	CASIO NP-100	BLI-349
	FUJI NP-40,40N	BLI-222
	FUJI NP-45	BLI-331
	FUJI NP-60	BLI-203
	FUJI NP-80	BLI-183
	FUJI NP-95	BLI-299
	FUJI NP-100	BLI-174
	FUJI NP-120	BLI-228
	FUJI NP-140	BLI-342

	OLYMPUS & FUJI	EMPIRE	
SIDE A	OLYMPUS BLM-1	BLI-240	
	OLYMPUS BLS-1	BLI-306	
	OLYMPUS Li10B,12B	BLI-224	
	OLYMPUS Li30B	BLI-257	
	OLYMPUS Li40B,42B	BLI-272	
	OLYMPUS Li50B	BLI-339	
	FUJI NP-45	BLI-331	
	FUJI NP-140	BLI-342	
	SIDE B	OLYMPUS Li20B	BLI-203
		OLYMPUS Li60B	BLI-355
FUJI NP-30		BLI-255	
FUJI NP-40		BLI-222	
FUJI NP-50		BLI-329	
FUJI NP-60		BLI-203	
FUJI NP-70		BLI-301	
FUJI NP-80		BLI-183	
FUJI NP-95		BLI-299	
FUJI NP-100		BLI-174	
SIDE B	FUJI NP-120	BLI-228	
	FUJI NP-150	BLI-317	

# SAMSUNG

# NIKON

# JVC

# KONICA/ MINOLTA

# PENTAX & RICOH & SANYO

## DVU-SAM1 R1

## DVU-NIK1 R1

## DVU-JVC1

## DVU-KOM1

## DVU-PRS1 R1



	SAMSUNG	EMPIRE
SIDE A	BP-85ST	BLI-335
	SB-P90,P180	BLI-282
	SB-P120,P240	BLP-302
	SLB-0637	BLI-259
	SLB-0737	BLI-222
	SLB-0837	BLI-288
	SLB-1137C	BLI-318
	SLB-1437	BLI-268
SIDE B	SB-L70,L110,220	BLI-200
	SB-L160,320,480	BLI-195
	SB-LH73	BLI-305
	SB-LH82	BLI-296
	SB-LS110,220	BLI-278
	SB-LSM80,160,320	BLI-271
	SLB-0837B	BLI-303
	SLB-0937	BLI-332
	SLB-10A	BLI-341
	SLB-11A <b>NEW</b>	BLI-370
SIDE B	SLB-1137D	BLI-314
	SLB-1237	BLI-295

	NIKON	EMPIRE
SIDE A	EN-EL12	BLI-354
	EN-EL1,1H	BLI-201
	EN-EL2	BLI-210
	EN-EL3,3a	BLI-211
	EN-EL3e	BLI-293
	EN-EL5	BLI-239
	EN-EL7	BLI-267
	EN-EL8	BLI-275
	EN-EL9, 9a	BLI-304
	EN-EL10	BLI-320
SIDE B	EN-EL11	BLI-345

	JVC	EMPIRE	
SIDE A	BN-V37,37U		
	BN-V408,416,428,438	BLI-192	
	BN-V707,714,733	BLI-270	
	BNV-107,114	BLI-202	
	BN-V712	BLI-160	
	BN-V812,814	BLI-162	
	BN-VF808,815,823	BLI-309	
	BN-VM200	BLI-265	
	SIDE B		

	KONICA/MINOLTA	EMPIRE	
SIDE A	DR-LB4	BLI-223	
	NP-1	BLI-281	
	NP-200	BLI-217	
	NP-400	BLI-238	
	NP-500/600	BLI-243	
	NP-700	BLI-259	
	NP-900	BLI-269	
	SIDE B		

	PENTAX & RICOH & SANYO	EMPIRE
SIDE A	PENTAX D-Li50	BLI-238
	PENTAX D-Li63	BLI-311
	PENTAX D-Li78	BLI-344
	PENTAX D-Li88 <b>NEW</b>	BLI-363
	PENTAX D-Li92 <b>NEW</b>	BLI-364
	RICOH DB-50	BLI-300
	RICOH DB-80	BLI-344
	RICOH DS-6365	BLI-331
	SANYO DB-L10	BLI-224
	SANYO DB-L40	BLI-294
SIDE B	SANYO DB-L80 <b>NEW</b>	BLI-363
	SANYO DS-5370	BLI-272
	PENTAX D-Li1	BLI-208
	PENTAX D-Li2	BLI-203
	PENTAX D-Li7	BLI-228
	PENTAX D-Li8	BLI-222
	PENTAX D-Li68	BLI-333
	PENTAX D-Li72	BLI-259
	PENTAX D-Li95 <b>NEW</b>	BLI-222
	RICOH DB-20	BLI-183
SIDE B	RICOH DB-30	BLI-174
	RICOH DB-34	BLI-228
	RICOH DB-40	BLI-203
	RICOH DB-43	BLI-228
	RICOH DB-60 DB-65	BLI-284
	RICOH DB-70	BLI-323
	SANYO DB-L20	BLI-244
	SANYO DB-L30	BLI-259
	SANYO DB-L50	BLI-236
	SANYO NP-40	BLI-222